



—
Meet delights for your home here



—
Home of Delights

USA office: Fontana **AUS** office: Truganina

GBR office: FDS Corporation Limited, Unit 4, Blackacre Road, Great Blakenham,
Ipswich, IP6 0FL, United Kingdom

If you're having difficulty, our friendly
customer team is always here to help.



USA:cs.us@costway.com
AUS:service.au@costway.com
GBR:cs.uk@costway.com


MESSAGE CHAIR **JL10063**

THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION.
PLEASE READ AND KEEP FOR FUTURE REFERENCE.



Before You Start

- ⚠ Please read all instructions carefully.
- ⚠ Retain instructions for future reference.
- ⚠ Separate and count all parts and hardware.
- ⚠ Read through each step carefully and follow the proper order.
- ⚠ We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- ⚠ Always place the product on a flat, steady and stable surface.
- ⚠ Keep all small parts and packaging materials for this product away from babies and children as they potentially pose a serious choking hazard.



Thanks for purchasing this product. Please read this manual instruction carefully in order to know how to use this product correctly before operation. Please pay more attention to some important safety warning and keep this manual book properly for future use.

Note: Our company reserves the right to change and explain the design of the product. If there is some difference between the product function in market circulation and the description in the manual, it is a normal update of the product, and our company will not inform you otherwise. The specific product function and color shall prevail in kind.

Safety Precautions Must be observed

- Please read all relevant instructions carefully before use.
- The notes marked here will help you to use the product safely and correctly.
- In order to clearly indicate the extent of harm and damage, precautions are divided into **"Warning"** and **"Caution"** that may be caused by incorrect use. Both of them are important for safety and must be followed.

 Warning	Indicates that serious injury or death may result from improper use.
 Caution	Indicates that misuse may cause minor injury or property damage.

- Please pay attention to the symbol before each safety item.

 Forbidden	Absolutely Prohibited
--	-----------------------

The following populations should not use this product

 Forbidden	■ This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. ■ Children should be supervised to ensure that they do not play with the appliance. ■ The appliance has a heated surface. Persons insensitive to heat must be careful when using the appliance. ■ Patients with osteoporosis. ■ Patients with severe heart disease and wearing implantable medical devices such as pacemakers and defibrillators that are susceptible to electromagnetic waves. ■ People who have a fever (above 38°C). ■ Pregnant women or shortly after childbirth and during their menstruation period. ■ People who follow medical advice and are prohibited from receiving massage due to thrombosis, aneurysm, severe varicose veins, or other circulatory diseases. Within two weeks after the appearance of blood clots, it is strictly prohibited to massage any form of body parts that have blood clots. ■ People with injuries or skin conditions.
---	--

 Forbidden	■ Unsupervised children under the age of 14, or anyone unconscious ■ People advised by their doctors to rest or those feeling unwell. ■ People with spinal abnormalities or scoliosis are prohibited from receiving this product due to medical advice due to other diseases. ■ People with wet bodies.
---	--

Important safety warnings

 Warnings	■ If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard. ■ Keep children away from the movable parts of this product. ■ Use a properly grounded power source that is compatible with this device. ■ Unplug the power cord after use or before cleaning to prevent personal injury or damage to the device. ■ Use this device according to the instructions in the manual. ■ Do not use any parts or accessories that are not recommended. ■ Do not use this product outdoors. ■ Do not use near open flames such as stoves, and do not smoke while using.
--	--

 Warnings	■ Do not use heating equipment such as electric blankets on this product. ■ Do not sit on the back of the chair, leg massagers, shoulders, armrests, or stand on the seat. ■ Please read the instruction manual before operation. ■ Never use this product for any purpose not listed in the manual. ■ Limit each use to 20 minutes. ■ Do not use this product if the cover or leather is broken or damaged. ■ Do not drop anything into this product. ■ Never fall asleep while using this product. ■ Do not use this product if you are intoxicated or feeling unwell. ■ Do not use this product within one hour of eating. ■ Do not apply excessive force when using this product to avoid injury. ■ Do not use for purposes other than massage. ■ Precautions: Keep away from children. Do not store near high temperatures or open flames. ■ Fully insert the power plug into the outlet and ensure secure contact during use. ■ When using an extension cord, only use nationally certified products. ■ Disconnect power when leaving the premises. ■ Immediately discontinue use and disconnect the
--	--

 Warnings	power if abnormal noise, odor, overheating, or malfunction occurs. ■ Do not power the unit from lamp socket outlets. ■ Total current draw of connected appliances must not exceed the rated current of the main outlet/circuit. ■ Never use near flammable/explosive materials. ■ Do not disassemble this product or modify its internal wiring, components, or safety features. ■ When unplugging, do not pull on the power cord. ■ Only use specified fuse ratings - never substitute with conductive materials or incorrect ratings. ■ Do not alter the trip settings of circuit breakers or residual current devices.
--	--

Safety precautions	
 Caution	■ Check whether voltage is consistent with the specification of this product. ■ Never insert or unplug the power cord with wet hands. ■ Do not allow water to enter this product to avoid electric shock or damage. ■ Do not pull the power cord when plugging or unplugging. Avoid rough handling.

 Caution	■ Do not damage the wire or modify the circuit of this product. ■ Do not clean electrical parts, such as the power switch or plug, with a wet cloth. ■ Stay away from this product during a power failure to avoid injury if power is suddenly restored. ■ Stop using this product immediately if it malfunctions, and contact us. ■ Stop using this product if you feel unwell, and consult your health care practitioner.
---	---

Product care and maintenance	
 Caution	■ This product should be maintained by the service center designated by the manufacturer only. No user should disassemble or maintain it without permission. ■ Do not forget to turn off the main power switch after usage. ■ Do not use this product if the power socket is loose. ■ If the product will not be used for an extended period, roll up the power cord and store it in a dry, dust-free environment. ■ Do not store this product at a high temperature or near open flame. Avoid prolonged exposure to direct sunshine.

 Warnings	■ Please clean this product with dry cloth. Never use thinner, benzene or alcohol. ■ The mechanism of this appliance is specially designed and does not require special maintenance. ■ Do not puncture this product with sharp objects. ■ Do not roll or pull this product on any uneven ground. Instead, it should be lifted before moving. ■ Please use this product intermittently. Do not keep it working continuously for a long period of time. ■ Allow intermittent operation - continuous long-term use is prohibited.
--	---

Storage conditions	
 Caution	■ Storage room temperature: 5°C to 40°C. ■ Relative humidity (RH) between 20% and 80%; free of corrosive gases, and a well-ventilated room.

Operating environment	
 Caution	■ Do not use this product in a highly humid environment, such as a bathroom. ■ Stop using this product immediately when the ambient temperature changes sharply.





 Caution	■ Do not use this product immediately after a sudden change in ambient temperature. ■ Do not use this product in environments with heavy dust or corrosive gases. ■ Do not use this product in confined spaces or areas with poor ventilation.
---	--

Solutions to ordinary malfunctions	
 Caution	■ If the motor sounds during operation of this product, this is the normal operation sound. ■ If the controller is not working normally, check if the power plug and socket are securely connected, and ensure the power switch is turned on. ■ If the rated working time is over, this product will automatically activate the power-off button; If this product keeps operating for a long period of time, the temperature protector will stop this product automatically. The product can be used again after half an hour. ■ Weight limit: 120kg. Heavier users should purchase our reinforced models.

Rotating function shelf (open state)


Caution

- ✗ Do not swing from side to side with force;
- ✗ Do not hang anything other than mobile phones and tablets;
- ✗ Do not place your hands on the capsule;



Place massage chair

Installation placement

Make sure there is enough space for the massage chair can be tilted at least 18.5 cm.

Do not expose the massage chair to direct sunlight or high-temperature environments (e.g., in front of heating devices). Place it in an area where it can avoid heat and direct sunlight. For long-term use in a fixed location, it is recommended to place a soft cushion underneath.



CAUTION

Installation parts

Calf mechanism installation instructions

1. Insert the cable and air pipe of the calf mechanism respectively into the sockets at the front of the steel frame assembly (Figure 1).
2. After the connection is completed, open the calf mechanism fixing covers on both sides of the steel frame assembly (Figure 2).
3. Raise the calf mechanism and put it into the slot and cover the fixing cover and finally fix it in place with 2 M4 screws (Figure 3).

The cushion should be large enough to cover the area where the chair and the footrest touch the floor.




Product lift instruction

Two-person lifting required due to product weight.



1. Please lift the massage chair when moving it on delicate surfaces, such as wooden floors.
2. When moving on similar surfaces, lifting is recommended to avoid damaging the casters. Be cautious when lowering the chair into the designated position to avoid hand or foot injuries. Do not release the chair until it is completely flat. To prevent floor damage, it is recommended to place a mat or protective covering on the floor.




Move method

Use the rear casters to move the massage chair. Tilt the chair backward approximately 45° as shown in the diagram to move it.




NOTE: Excessive force to tilt will cause the chair to tip over completely and product damage.

1. Before moving, ensure the massage chair is properly powered off, with both the backrest and calf sections fully reset, and the power supply disconnected.
2. The chair should remain empty during movement; no people, pets, or objects should be on it.
3. Do not move the chair over obstacles higher than 2mm or gaps wider than 5mm.
4. When moving the chair using the casters, avoid continuous movement over distances greater than 50 meters. If necessary, move the chair slowly and at a steady pace.



How to disassemble and use headrest cushion and backrest cushion


Using a headrest cushion can reduce the intensity of kneading massage on the neck and shoulders, and you can decide whether to use a headrest cushion according to your needs (recommended to use a headrest cushion). The backrest cushion and the backrest are connected by a zipper (1), and the headrest cushion and the backrest cushion are connected by a zipper (2).



Before Use

Check around

Make sure that there are no people, pets and other objects around the unit.




Make sure there are no foreign objects in the gaps of the machine

Before massaging, make sure that no foreign objects are caught in the legs, feet, etc.


Under no circumstances should hands, feet, or head be allowed to enter the area between the lower leg mechanism and main body, or the area between the armrest and the capsule.

Under no circumstances should hands, feet, or head sink under the fabric or leather covering of the massage area.




Turn on the power


Caution



Plug in power cord



Schematic diagram of power on




Turn on the power switch ("I" position)

Warnings

- Please check the power cord and plug for damage before use.
- Please supply power to this product in accordance with the working power requirements of this product's calibration.
- It is strictly forbidden to use a power supply other than the nominal power supply of this product.
- It is strictly forbidden to connect various power conversion devices without authorization to supply power to this product.

Product Structure

Description of components



1.Light board

2.Remote control

3.Remote control holder

4.Shawl components

5.Ambient Light

6.Leg massage components

7.Mobile phone holder

8.Head cushion

9.Speaker cover components

10.Shoulder

● Air pressure components


11.Armrest

● Air pressure components

12.Armrest

13.Side cover

Schematic view of functional distribution



1.Both sides of shoulder

- Air bag massage

2.Arm

- Air bag massage
- Armrest shortcut key
- Voice control function
- Built-in voice control microphone

3.Right hand

- Air bag massage

- Shortcut keys

- Raised point massage belt and magnetic therapy

4.Foot

- Airbag massage
- Roller massage
- Electrically adjustable foot telescopic
- Automatic leg length detection

5.Both sides of head

- 3D digital audio
- Music player

6.Head and neck to seat

- Mechanism massage

7.Shoulder,back,Waist,abdomen

- Shawl heating

- Raised point massage belt and magnetic therapy

- Air bag massage

- Wireless charger


- USB charger

- Airbag massage

- Leg kneading


How to use the shawl

It features a unique shawl component, with innovative heating functions on the shoulder, back, waist and abdomen. Users can place the shawl at different massage positions according to massage requirements.




Schematic diagram of use on back and waist

When the shawl component is placed on the back and waist position, the shawl built-in heating, dredge the back meridians, promote blood circulation and warm the kidney, relieve low back pain, back cold stiffness, pain and other conditions.



Schematic diagram of use on shoulder and abdomen

When the shawl component is placed at the shoulder position (front/rear), it will heat the acupoints such as Bingfeng, Tianzong, Yunmen and Qihu around the shoulder and clavicle through the shawl built-in heating; it can also be placed on the abdomen to heat the abdomen through the shawl built-in heating.





Use demonstration of the shawl on the back




1. Correct placement and use: When the shawl is used on the back (or the massage chair is not turned on), please place the shawl on both sides of the backrest and put the lower magnet and the backrest cushion lumbar position of the magnet corresponding suction well; if you do not need to use the shawl function, level the shawl and lift back behind the massage chair.

2. Wrong placement and use: When the shawl is used on the back (or the massage chair is not turned on), do not bring the shawl together in the middle manipulator massage area, which may lead to functional failure, product failure and other serious faults. At the same time, do not fold, twist, cross the shawl, and place and use the shawl on your back.



Remote controller keys instruction




1. On/off key: Turn the massage chair on or off.
2. Home key: Quickly return to the main interface function.
3. Pause key: Pause the massage or exit from pause massage
4. Auxiliary function key: Select the corresponding massage function.
5. Speed/Intensity key: Enter the massage speed/intensity interface to adjust 4D intensity and massage speed.
6. Intensity selection key: Select massage intensities
7. Automatic function key: Enter the automatic massage program selection function.

8. Manual mode key: Enter the manual massage function interface.

9. Angle adjustment key : Enter the angle adjustment interface to select the sitting posture angle.

10. Storage key: Enter the storage interface

11. Air pressure massage key: Select the corresponding air pressure massage and air pressure intensity adjustment.




12. Air pressure display status: Display the current air pressure massage position.

13. Shoulder position adjustment down key: Adjust the shoulder position downward to determine the massage benchmark.

14. Shoulder position adjustment up key: Adjust the shoulder position upward to determine the massage benchmark.


- 15. Time adjustment key: Adjust the massage time.
- 16. Setting key: Enter the setting menu interface.
- 17. Massage mechanism display status: Display the current massage mechanism position.
- 18. Status display bar key: Display the massage program status information.

Armrest shortcut key description




- 1. 4D+- key: Rotate this key clockwise, 4D intensity increases, up to 5th level. Rotate this key counterclockwise, 4D intensity decreases, lowest 1 level.
- 2. Automatic program key: Press this key to cycle through 20 automatic modes.
- 3. Heating key: Press this key to turn on or off the backrest heating function.

- 4. Manual key: Press this key to cycle in Knead (7 modes in total), Tap I, Tap II, Knead & Tap, Shiatsu I, Shiatsu II, Shoulder grasp, 4DI, 4DII, 4DIII and 4DIV and no technique.
- 5. Air pressure key: Press this key to cycle the air pressure intensity between level 1 to 5.



- 6. On/off key: Long press this key for 3 seconds to turn on or off the massage chair. After starting the massage, short press to pause/run.




- 7. Voice control key: Long press to turn on or off the voice assistant function, short press to wake up the voice assistant.
- 8. Linkage up and down key: Push this key upward to slowly raise the backrest and lower the leg rest slowly. Release it to stop the backrest rising and the leg rest lowering. Push this key down and the backrest slowly lowers, while the leg rest slowly rises.
- 9. Zero gravity key: Short press this key to automatically adjust the zero gravity angle, two levels can be adjusted. To zero gravity level two, press the zero gravity key to turn off zero gravity.

Operation Instructions


I.Start Massage

- 1.Press the On/Off key on the remote control or long press the On/Off key on the right armrest to turn on the chair.
- 2.After the system is started, select the massage intensity by clicking on any one of the Gentle, Soothing or Strong keys on the remote control to turn on the massage chair and enter the lying state. If it is not selected within 5 minutes,the massage chair will turn off automatically.




- 3.After the system is started, then enter the lying state, select the "Zero 1" or "Zero 1" key, then the massage chair will be automatically adjusted to zero-gravity angle, and wait until its adjustment is completed. Also can press the "Skip" key to go directly to the next step.

- 4.Wait until body shape detection is completed, also can press the "Skip" key to skip detection and start massage directly.



5. For fine adjustment of shoulder position, after body shape detection, the remote control or a voice prompt will remind the user of fine adjustment of shoulder position. If the massage roller stops at the shoulder position, directly press the "OK" key to start massage. If not, click the Up key and Down key to adjust the massage roller to your appropriate shoulder position (there are 0-10 levels shoulder position adjustable), and then press the "OK" key to start the massage. If no operation is made within 10s, directly default the current massage roller position for the shoulder position and start massage.





After the massage chair is turned on, press the "pause" (⏸) key to enter the pause state, then all massage functions will be stopped, and press the "pause" (▶) key again to resume the previous massage state. Note: In the pause state, all functions do not work except shutdown.

III. Intensity selection (please use this function after turning on the massage chair)

During the massage process, you can also click the "Select Intensity" (🏠) key in the "Home" (Select level) interface. As shown in the figure below, and then select the "Soft, Soothing, Strong" keys in the pop-up interface according to the massage intensity needs to turn on different massage intensities.


II. Pause function (please use this function after the chair is turned on)



IV. Auto mode(please use this function after the chair is turned on)

1.Auto program: As shown in the figure below, click the "Auto"  key in the menu bar at the bottom of the screen to enter the automatic program selection interface. Then select different automatic massage functions for massage according to your massage needs.

(1).Swipe left and right in the automatic program interface to select 4 different massage scenes: Family exclusive (including Comfort massage, Relax massage, Full body massage, Office Regimen, Health Recharge), scene application (including Energy Boost, Lunch Break, Sweet Dream, Brain Refresh, Rejuvenate), Health care (including Total Relax, Stress Release, Full Airbag, Chinese Massage, Stretch massage), Special procedures (including Meridian Treatment, neck & shoulder care, waist care, Waist and buttock Shape, Leg&foot Relieve), there are 20 automatic programs to select.



Automatic Mode Selection Schematic

Massage scenes (Exclusive for Family)	
Function	Description
Comfort massage	With the aid of flexible guide rails, let the body posture angle closer to lying flat; with the effective anti-arch stretching of 3D movement to the back, achieve zero pressure stretching, effectively relieve lumbar muscle pain, and eliminate fatigue, thus to get a better massage experience, relieve the stress on the body and mind.
Relax massage	Massage the neck and shoulders by means of kneading and stretching techniques mainly, and also the upper back by medical massage, and then press the Jianjing acupoint to relieve cervical spondylosis and achieve the effect of relaxing the muscles of the neck and shoulders. Massage intensity is gentle, suitable for people working in office and suffering from cervical fatigue.
Full body massage	Mainly use anti-kneading, positive and negative kneading techniques to do back-opening massage on the entire back, combined with flapping and shiatsu techniques, the massage intensity is moderate, suitable for people with back congestion and poor blood flow.
Office Regimen	Massage the shoulders, neck and waist by means of kneading, tapping, kneading and tapping techniques mainly, to relieve shoulder and neck pain, improve lumbar muscle soreness and maintain lumbar spine through such deep massage. It is suitable for office white-collar and sedentary people.

Function	Description
Health Recharge	Massage the shoulders and waist by means of kneading, patting, kneading and patting mainly, apply air massage on the legs and feet for squeezing massage, allowing more soothing leg and foot massage, suitable for sedentary people with low stress on the legs and feet, not only relieving the cervical spine, lumbar spine pain of sedentary people, but also soothing the legs and feet. Massage intensity is gentle.

Massage scenes(Relaxing and Activating)

Function	Description
Energy Boost	Massage the waist, shoulders and neck by means of kneading, patting, kneading and patting techniques, to awaken the body's vital energy, stimulate physical energy through such deep massage of the whole body with the massage intensity being heavy, which is suitable for people with strong stress, such as athletes, for stimulating the potential before a race.
Lunch Break	Massage the back and waist by means of kneading and patting techniques, and press the Shenyu acupoint, to improve the quality of lunch break, so that the user is more energetic in afternoon work. It is suitable for office workers, and the massage intensity is gentle.

Function	Description
Sweet Dream	Massage the shoulders, neck, back and waist by means of kneading and medical massage techniques, and press the acupoints of Fengchi and Shenyu, to improve the sleep quality and help sleep. It is suitable for people suffering from poor sleep.
Brain Refresh	Massage the shoulders, neck and back and waist by means of kneading, 4D kneading and Shiatsu techniques to achieve a high degree of physical and mental harmony through deep massage. It is suitable for people who are mentally retarded and overused. The massage intensity is gentle.
Rejuvenate	Mainly massage the shoulders & neck, back & waist with kneading, 4D kneading and shiatsu. Suitable for people who are mentally stressed, physically and mentally unbalanced. The massage intensity is gentle.

Massage scenes(AI Intelligent)


Function	Description
Total Relax	Massage the shoulders, neck, back and waist by means of kneading, patting, kneading and patting mainly, to relieve fatigue, promote blood circulation, and release stress by such deep massage. It is suitable for men, and the massage intensity is moderate.

Function	Description
Stress Release	Massage the shoulders, neck, waist and hips by means of kneading and finger pressing techniques, through the massage on the whole body, to relax the body and mind, and enjoy the queen-level treatment. It is suitable for women, and the massage intensity is gentle.
Full Airbag	Apply air massage on the whole body, with the foot roller and calf kneading massage. Calf stretching function is canceled, suitable for the elderly and people suffering stress on back. The massage intensity is gentle.
Chinese Massage	By means of Traditional Chinese medicine massage technique mainly, apply 4D massage on the back and waist so as to promote the blood circulation of the back and waist, soothe the meridians and relieve the blockage of the back and waist through massage. It is suitable for people with back and waist pain, and lumbar muscle strain. Massage intensity is gentle.
Stretch massage	Mainly use calf and backrest electric push rod to clamp legs, hands and shoulders with the aid of air massage, and then apply stretching massage, while the movement holds against the back and waist for 3D medical massage, so that the body is in the Thai stretching state. It is suitable for people under high stress to improve their head-down on chest and humpback. Massage intensity is strong.

Massage scenes(Overall Relaxation)	
Function	Description
Meridian Treatment	The legs, hands and shoulders are mainly clamped by air pressure, and the massage chair automatically adjusts various angles to achieve the effect of stretching and traction. Suitable for people who practice yoga. The massage intensity is moderate.
Neck & shoulder Care	Massage the neck and shoulders by means of kneading and stretching techniques mainly, and also the upper back by medical massage, and then press the Jianjing acupoint to relieve cervical spondylosis and achieve the effect of relaxing the muscles of the neck and shoulders.
Waist care	Mainly massage the back and waist with flapping and kneading techniques to promote blood circulation and eliminate local muscle soreness. Suitable for people with long-term weight-bearing activities and muscle strain. The massage intensity is moderate.
Waist & Buttock shape	Massage buttocks by kneading and medical massage mainly, and then through patting and kneading, deeply massage buttocks and perineum, to relax the hip muscles and lift the hip, which is suitable for women massage, and also for men for maintenance of prostate.

Function	Description
Leg&foot Relieve	Massage the shoulders, neck and back and waist by means of kneading, patting and finger pressing techniques. At the same time, drag the calves to achieve the function of knee joint movement. Such deep massage can obtain the effect of exercise. It is suitable for people with less exercise, and the massage intensity is moderate.

V. Remote program (please use this function after the equipment is turned on)



1. Manual program: As shown in the figure below, select and click the "Manual  " key in the menu bar below to enter the manual menu,


and then select the massage technique, massage area, mechanism adjustment, massage width, massage speed, 4D intensity and other massage functions.

(1). Massage technique: Select a massage technique in the manual mode interface, including no technique, knead (a total of 7 modes to cycle switch), tap (a total of 2 techniques), knead & tap (a total of 1 technique), and shiatsu (a total of 2 techniques), grasp (a total of 1 techniques), 4D (a total of 4 techniques) and other 17 options.

Function	Massage mechanism adjustment	
Stop		Press this key to massage without any technique.
Knead (7 types)		The speed, intensity can be adjusted.
Tap (2 types)		The speed, width, intensity can be adjusted.
Knead&Tap (1 types)		The speed, intensity can be adjusted.
Shiatsu (2 types)		The speed, width, intensity can be adjusted.
Grasp (4 types)		The speed, intensity can be adjusted.
4D (1,2 types)		The speed, intensity can be adjusted.
4D (3,4 types)		The speed, width, intensity can be adjusted.

5 speed levels adjustable
5 width levels adjustable
5 intensity levels adjustable

2. Message area: As shown in the figure below, select the "Message area" key in the manual program interface, and then select the message area according to the message needs in the pop-up window interface. The message area menu has five options: Spot, Partial, Full, Upper and Lower. Select the corresponding message area for massage.




Manual mode-Schematic diagram of message area selection


Key	Description
Spot	Fixed-point massage at fixed-point position.
Partial	Small-scope local massage back and forth.
Full	Full back massage back and forth.

Key	Description
Upper	Upper back massage back and forth
Lower	Lower back massage back and forth

3. Mechanism adjustment: As shown in the figure below, select the "Mechanism" key in the manual program interface, and then press and hold the "Up or Down" key in the pop-up window to move the mechanism up and down according to the massage needs. Release it to stop the movement of the mechanism. There are 1-10 levels position adjustable; the mechanism adjustment needs to be adjusted in the spot and partial message area.




Manual mode - Schematic diagram of mechanism adjustment selection




Key	Description
	Press and hold the up key to move the mechanism upward, and release the key to stop the mechanism from moving upward. There are 1-10 adjustable levels.
	Press and hold the down key to move the mechanism downwards, and release the key to stop the mechanism from moving downwards. There are 1-10 adjustable levels.

4.4D intensity adjustment: As shown in the figure below, select the "4D intensity" slider in manual mode, and then slide left or right to adjust the 4D intensity according to the massage needs. There are 1-5 levels of adjustable intensity, with level 1 being the weakest intensity, level 5 being the strongest intensity. The stronger the 4D intensity, the higher the massage wheel will push out, and the stronger the massage intensity will be.




Key	Description
	Press and hold the sliding key and slide to the right to increase the 4D intensity. There are 1-5 levels intensity adjustable.
	Press and hold the sliding key and slide to the left to weaken the 4D intensity. There are 1-5 levels intensity adjustable.




Manual Mode - schematic diagram of 4D intensity

Note: You can also click the "Speed/Intensity Speed/Intensity **Speed/Intensity**" key on the Home interface to enter the speed/intensity adjustment interface as shown in the figure below, and then select the "4D intensity" slider key according to your massage needs and slide left or right to adjust the 4D intensity. There are 1~5 levels intensity adjustable, with level 1 being the weakest

intensity, level 5 being the strongest intensity. The stronger the 4D intensity, the higher the massage wheel will push out, and the stronger the massage intensity will be.




Home-Schematic diagram of 4D Intensity/Massage speed




Key	Description
	Slide the button to the right to increase the 4D intensity, with a range of 1-5 for adjustment.
	Slide the button to the left to decrease the 4D intensity, with a range of 1-5 for adjustment.

5.Massage speed: As shown in the figure below, select the "Massage Speed" slider key in manual program, and then slide left or right to adjust the massage speed according to the massage needs. There are 1- 5 levels massage speed adjustable, with level 1 being the slowest speed, level 5 being the fastest speed, and the speed cannot be adjusted when the massage technique is stopped. (1).The speed can be adjusted only when the user enters the manual program in selecting massage technique or massage area.




Manual Mode-Schematic diagram of massage speed



Key	Description
	Press and hold the sliding key and slide to the right to increase the massage speed. There are 1-5 levels speed adjustable.
	Press and hold the sliding key and slide to the left to down the massage speed. There are 1-5 levels speed adjustable.

Note: You can also click the "Speed/Intensity" key on the Home interface to enter the speed/intensity adjustment interface as shown in the figure below, and then select the "speed" slider key according to your massage needs and slide left or right to adjust the speed. There are 1- 5 levels massage speed adjustable, with level 1 being the slowest speed, level 5 being the fastest speed, and the speed cannot be adjusted when the massage technique is stopped.




Home Status-Schematic diagram of Massage speed

				
Level 1	Level 2	Level 3	Level 4	Level 5


Key	Description
	Press and hold the sliding key and slide to the right to increase the massage speed. There are 1-5 levels speed adjustable.
	Press and hold the sliding key and slide to the left to down the massage speed. There are 1-5 levels speed adjustable.

6. Massage width: As shown in the figure below, select the "Massage width" slider key in manual program, and then slide left or right to adjust the massage width according to the massage needs. There are 1- 5 levels massage width adjustable, with level 1 being the narrowest width, level 5 being the widest width. Please use it in the following massage techniques: No technique, Tap, Shiatsu and Knock.

(1).The width can be adjusted only when the user enters the remote mode in selecting massage technique or massage area.

				
Level 1	Level 2	Level 3	Level 4	Level 5


Key	Description
	Press and hold the sliding key and slide to the right to increase massage width. There are 1-5 levels width adjustable.
	Press and hold the sliding key and slide to the left to decrease massage width. There are 1-5 levels width adjustable.



Manual Mode-Schematic diagram of massage width




7.Air pressure massage: As shown in the figure below, select the “Air pressure massage”key” on the home interface, and then select the corresponding air pressure massage function in the pop-up window according to your massage needs. The air pressure programs include upper body, lower body, full body and air pressure intensity adjustment. The air function will be disabled when all above modes are off.

Note: You can also press the “Air pressure massage” key in the “Home” interface and select the corresponding air pressure mode in the pop-up menu. (The function here is the manual function - the shortcut of air pressure massage in the Home page)




Home Mode-Schematic diagram of air pressure massage


Key	Description
Off	Press this key to disable the air pressure function.
Upper body	Press this key to enable or disable the upper body air massage function.
Lower body	Press this key to enable or disable the lower body air massage function.
Full body	Press this key to enable or disable the whole body air massage function.

Air pressure display		
Upper body air pressure	Lower body air pressure	Whole body air pressure
		

8.Air pressure intensity: As shown in the figure below, select the "Air Pressure Massage " key on the home page. After the air pressure massage function is turned on in the pop- up window, you can slide the "Air pressure intensity" slider left or right to adjust the intensity according to the massage needs. There are 5 levels of intensity adjustment available, with level 1 being the weakest intensity, level 5 being the strongest intensity. The air pressure intensity can be adjusted, and the air pressure intensity is divided into 5 levels.




Home Mode-Schematic diagram of air air pressure intensity



Key	Description
	Press and hold the sliding key and slide to the right to increase the air pressure intensity. There are 1-5 levels intensity adjustable.
	Press and hold the sliding key and slide to the left to weaken the air pressure intensity. There are 1-5 levels intensity adjustable.

VI. Sitting Posture Adjustment

Click the "Angle"  key in the menu bar below the display screen to enter the angle adjustment interface, which includes leg rest up and down, linkage up and down, backrest up and down, zero gravity I, zero gravity II, etc. massage functions.



Schematic diagram of sitting posture adjustment

1.Zero-gravity adjustment

Key	Description
	Zero-gravity I key: automatically adjust the position of leg unit and backrest unit to zero-gravity I position.
	Zero-gravity II key: automatically adjust the position of leg unit and backrest unit to zero-gravity II position.

2.Telescopic adjustment of footrest

Key	Description
 Foot shorten	Footrest shortening button: Manually adjust the footrest to shorten; press and hold this button to move the footrest slowly upward, and release it to stop. When adjusted to the limit position, the adjustment will stop and a "Didi" prompt sound.
 Foot extend	Footrest extension key: Manually adjust the extension of the footrest; press and hold this button to move the footrest slowly downward, and release it to stop. When adjusted to the limit position, the adjustment will stop and a "Didi" prompt sound.

3.Leg unit extension/shortening adjustment

Key	Description
	Leg unit Up key: press and hold this key to slowly raise the leg unit, and release it to stop rising; When adjusted to the limit position, the adjustment will stop and a "Didi" prompt sound. rising action is completed, the leg unit will automatically detect the foot length.
	Leg unit Down key: press and hold this key to slowly lower the leg unit, and release it to stop lowering; When adjusted to the limit position, the adjustment will stop and a "Didi" prompt sound. lowering action is completed, the leg unit will automatically detect the foot length.

4. Linkage lifting Angle adjustment


Key	Description
 Whole up	Linkage Up key: press and hold this key to slowly raise the backrest unit while slowly lowering the leg unit, and release it to stop raising the backrest unit or lowering the leg unit; When adjusted to the limit position, the adjustment will stop and a "Didi" prompt sound. when rising action is completed, the leg unit will automatically detect the body height.
 Whole down	Linkage Down key: press and hold this key to slowly lower the backrest unit while slowly raising the leg unit, and release it to stop lowering the backrest unit or raising the leg unit; When adjusted to the limit position, the adjustment will stop and a "Didi" prompt sound. when lowering action is completed, the leg unit will automatically detect the body height.

5.Backrest unit angular adjustment

Key	Description
	Backrest unit Up key: press and hold this key to slowly raise the backrest unit and release it to stop rising. When adjusted to the limit position, the adjustment will stop and a "Didi" prompt sound.
	Backrest unit Down key: press and hold this key to slowly lower the backrest unit and release it to stop lowering. When adjusted to the limit position, the adjustment will stop and a "Didi" prompt sound.


VII. Memory (please use this function after the chair is turned on)

Click the "Memory"  key in the menu bar below the display screen to enter the message function storage selection interface as shown in the figure below, with two categories including message function storage and message function call; there are 3 groups of message function storage and 3 groups of message function call.



Key	Description
 Save	Save: Save the current running message functions, including automatic function, message technique, air pressure mode and intensity, the angle of the leg and backrest mechanisms and other message functions.
 Use	Use: Use previously saved message functions, including automatic function, message technique, air pressure mode and intensity, the angle of the leg and backrest mechanisms, and other message functions.

VIII. Setting (please use this function after the chair is turned on)



Click the "Settings"  key in the menu bar at the bottom of the display screen to enter the setting interface as shown in the figure below, can view the product number and software version number. You can also perform system settings in the interface, including Bluetooth, voice broadcast, voice control, volume, light, language selection and other system setting functions.

- 1.Product model and software version show the current equipment and other information.
- 2.Bluetooth: After entering the setting interface as shown below,click the "Bluetooth" switch to turn on or off the Bluetooth function.After the Bluetooth function is turned on, the audio source device with Bluetooth function (such as mobile phone, MID tablet, etc.) can be paired and connected with the Bluetooth module of the massage chair, and the music played by the audio source device can be

transmitted wirelessly to the massage chair sound system through Bluetooth for music playback.


- (1).Enter the smart device main menu. Open "Settings" and select the "Bluetooth" option.

Open "Bluetooth", and Bluetooth will automatically "Search for a New Bluetooth Device".

- (2).The smart device will search for the corresponding Bluetooth model (e.g. IMCM- XXXX). Click the "Match" button. If you are asked whether to match with the device, you just select "Match" to complete matching.

- (3).Turn on "Music Player" in the smart device and select the song to play.

3.Voice Control: Click the "Voice Control" switch as shown in the figure below to turn on or off the voice control function. After you turn on the voice function, you can voice control your massage chair according to the voice entry words.



(1).When massage chair is on, close to the right armrest position to say “Hi Alice” or “Hey Alice” to wake up the voice assistant (If unable to wake up, please enter the setting interface to check whether the voice control switch is on or not, if not, please turn on the voice control switch), when the voice assistant replies "I'm here" on behalf of the awakening, you can use the voice control assistant function to control the massage chair.

(2).You can also short press the “Voice key ”button in the armrest shortcut key to wake up the voice assistant, and long press and hold this key for 3 seconds to turn it on or off.

(3).After the voice assistant wakes up, please say the command within 6 seconds to realize the function control of the Massage chair. After the voice assistant responds to the command, you can continue to say the command. The interval between two adjacent commands cannot exceed 6 seconds, otherwise you need to wake up the voice assistant again. The detailed voice command table is as follows:


Attention: When awakening the voice control function, the speaking speed should not be too fast, and voice commands should be issued according to Voice Control Entry.

Voice Control Entry		
Entry: “Hi Alice” or “Hey Alice”. Answer: I am here.		
No.	Voice control entry	Answer entry
1	Massage on	Answer: Ok, Massage on
2	Massage close	Answer: Ok, Massage close
3	Comfort Massage	Answer: Ok, Comfort Massage
4	Relax massage	Answer: Ok, Relax massage
5	Full body massage	Answer: Ok, Full body massage


Voice Control Entry		
Entry: “Hi Alice” or “Hey Alice”. Answer: I am here.		
No.	Voice control entry	Answer entry
6	Energy Boost	Answer: Ok, Energy Boost
7	Lunch Break	Answer: Ok, Lunch Break
8	Stretch massage	Answer: Ok, Stretch massage
9	Sweet Dream	Answer: Ok, Sweet Dream
10	Total Relax	Answer: Ok, Total Relax
11	Neck & Shoulder Care	Answer: Ok, Neck & Shoulder Care
12	Waist Care	Answer: Ok, Waist Care
13	Open the air pressure	Answer: Ok, Open the air pressure
14	Close the air pressure	Answer: Ok, Close the air pressure
15	Up the seat position	Answer: Ok, Up the seat position
16	Down the seat position	Answer: Ok, Down the seat position
17	Change the other mode	Answer: Ok, Change the other mode
18	Go little down	Answer: Ok, Go little down
19	Go little up	Answer: Ok, Go little up

Note: commands 18 and 19 can only be used after command 17


4.Voice broadcast: Enter the setting interface as shown in the figure below, and then click the "Voice broadcast" key to turn on or off the voice broadcast function. After turning on the voice broadcast function, the voice assistant will broadcast the automatic program and zero gravity gear selected by the user when using the massage chair.




5.Volume: Enter the setting interface as shown in the figure below, then click the "Volume" slider and slide left or right to adjust the voice volume according to the massage needs. There are 0-15 adjustable volume levels.



6.Ambient light: Enter the setting interface as shown in the figure below, and then click the "Light" key to turn on or off the space capsule lights.




7.Language selection: After entering the setting interface as shown below, select different languages according to the user's needs. The default language is English and Chinese can be selected.




IX. Other Functions (Please use these functions after the device is powered on)


1. On the "Home" interface, as shown in the figure below, select the "Assistive Functions" key, and then choose the "Back Heating" key in the pop-up menu to turn on or off the back heating function. After turning on the heating function, it will become warm in 3 minutes.




2. On the "Home" interface, as shown in the figure below, select the "Assistive Functions" key, and then choose the "Foot Rollers" key in the pop-up menu to turn on or off the foot roller massage function. There are three adjustable speeds: low, medium, high, and off.





3. On the "Home"  interface, as shown in the figure below, select the "Assistive Functions"  key, and then choose the "Calf Kneading"  key in the pop-up menu to turn on or off the calf kneading massage function. The inner side of the calf is equipped with kneading massage function, while the outer side has airbag compression massage function to relieve stiffness or tension in the calf caused by prolonged standing.



4. On the "Home"  interface, as shown in the figure below, select "30:00" and then use the plus or minus keys in the pop-up menu to increase or decrease the massage time. Click the "+" key to add 5 minutes, up to a maximum of 30 minutes. Click the "-" key to reduce 5 minutes. Alternatively, you can directly choose preset massage times of "10 minutes, 20 minutes, 30 minutes".





5. On the "Home"  interface, as shown in the figure below, select the  "Position"  key, and then use the up and down keys to adjust the shoulder position. There are 11 adjustable levels totally.




X. Massage OFF

During the massage process, press the "POWER" key on the top of the remote control or long press the "on/off key" on the right armrest to turn off the massage chair. Immediately turn off all massage functions and the backrest mechanism and leg mechanism reset, or when the massage timer expires, the massage will automatically turn off all massage functions and the backrest mechanism and leg mechanisms will not reset.


POWER key




Cut off the whole machine power supply, as shown in the figure (Schematic diagram of power switch position of the whole machine).



Turn off the power switch ("0" position)



Schematic diagram of pulling out the power plug



Remove the product connection power cord

Cleaning and Maintenance

Cleaning synthetic leather and plastic parts

Wipe the leather with a soft, dry cloth.

- Do not use chemicals such as thinner, gasoline, alcohol, etc. to clean the unit.
- When using commercially available leather care products (rags), please follow the instructions for use.
- If synthetic leather is particularly dirty, wipe it in the following way.
 - ① Immerse a soft cloth in water or hot water containing 3% to 5% neutral detergent, then wring it out thoroughly.
 - ② Use the above soft cloth to wipe the leather surface.
 - ③ Wipe off the cleaning solution with a cloth soaked in clean water and thoroughly wring out.
 - ④ Wipe with a wrung soft cloth.
 - ⑤ Let it air dry naturally.
- When it is difficult to remove stains, please immerse commercially available melamine foam in neutral detergent, and then wipe the machine with it.
- Do not use a hair dryer to dry the surface.
- Be careful when wiping the machine with denim and colored fabrics, as the color of the fabric will stain the surface of the synthetic leather.
- Do not keep these parts in contact with plastic for a long time, as this will cause discoloration.
- Synthetic leather may be discolored, so when using hair dye, please cover the touched part with a towel.



Troubleshooting

Fault	When the calf mechanism or the backrest reaches a certain position, press the corresponding adjustment button and it will no longer change, and a continuous "beep, beep" sound will be emitted.
Solution	Due to product structure design and ergonomic requirements, this product has a limited protection design for the limit state of attitude adjustment. At the same time, a reminder sound will sound when the limit is reached.

Fault	The function does not work or some functions do not work after the machine is turned on.
Solution	After the machine is turned on by pressing the switch key, it is necessary to manually select an automatic massage program or other working state. If it is not operated, the machine will automatically shut down after 20 minutes. If the manual operation mode is selected, the functions that are not selected may be disabled, and the working mode needs to be manually set in the manual mode.

Fault	The machine makes a leather rubbing sound when adjusting its posture.
Solution	This product adopts high-grade anti-corrosion leather that meets environmental protection requirements. Due to the inherent characteristics of leather materials, there will be a normal slight noise when rubbing at the relative movement, which is a normal phenomenon. Note: If you hear fabric or leather tearing sound when the machine is running, please stop using it immediately and seek professional maintenance.

Fault	The massage wheel did not reach the shoulders or neck.
Solution	If the head does not touch the head cushion or the back does not touch the backrest, the shoulder position may be lower than the actual position during the body shape detection process. Sit in the deepest position of the seat, rest your head on the headrest, and start over from the beginning.

Fault	The unit is damaged. The power cord or power plug is abnormally hot.
Solution	To prevent accidents, be sure to contact an authorized service center.

Please feel free to contact the designated service personnel for any questions or doubts about this product.

Product specifications

Model: A553-2 (JL10063)

Name: Massage Chair

Rated voltage: 220-240V~ 50Hz/60Hz

Rated power: 150W

Rated time: 20min

Safety structure: Class I



Return / Damage Claim Instructions

- ⚠ **DO NOT discard the box / original packaging.**
In case a return is required, the item must be returned in original box. Without this your return will not be accepted.
- ⚠ **Take a photo of the box markings.**
A photo of the markings (text) on the side of the box is required in case a part is needed for replacement. This helps our staff identify your product number to ensure you receive the correct parts.
- ⚠ **Take a photo of the damaged part (if applicable).**
A photo of the damage is always required to file a claim and get your replacement or refund processed quickly. Please make sure you have the box even if it is damaged.
- ⚠ **Send us an email with the images requested.**
Email us directly from marketplace where your item was purchased with the attached images and a description of your claim.